



# CEB: Wide Cylinder Supports

Written By: Brianna Kufa



## TOOLS:

- [Angle grinder \(1\)](#)
- [Square \(1\)](#)
- [Welder \(1\)](#)
- [torch \(1\)](#)



## SUMMARY

[Sketchup Model](#)

Additional Materials Required:


3/4"x2" Bolts (2) 3/4" Steel Nuts (2) 3/4" Galvanized Nuts (2)

## Step 1 — CEB: Wide Cylinder Supports



- Torch the hole in the 2x2 angle as shown.
- Weld the angle centered on the U-channel
- Weld a 3/4" bolt over the hole.

## Step 2



- Put a galvanized nut on a 3/4"x2" bolt and thread through the welded nut on each side

This document was last generated on 2012-11-03 03:45:15 AM.